



# ILLUME MEDICINE CABINET INSTALLATION INSTRUCTIONS

Dear AFINA Customer:

We appreciate your purchase of our AFINA Bath Cabinet, and would like to provide you with the following helpful hints.

1. For protection in shipping, the **GLASS SHELVES & SHELF PINS** for your cabinet have been neatly placed inside the cabinet body. Please **look carefully** and remove before installation.
2. It is important to make sure the cabinet body is level and plumb upon installation. Use a leveling instrument to ensure accuracy, or the door may not close and/or secure itself properly.
3. **WHEN RECESSING**, You must make a small notch in your frame **STUD**, on the side that the electrical wires comes out to allow the cabinet to sit flush **AND** wires go through the back to electrical connection.
4. When **RECESSING** the cabinet, use the two pre-drilled the holes on each side of the cabinet interior (top and bottom). Screws are **not** supplied, as we do not know the type of material you are going into (i.e. wood studs, metal studs). Make sure the cabinet is level and plumb before securing into framing studs.
5. When **SURFACE MOUNTING** - See separate "**OPTIONAL**" **SURFACE MOUNTING INSTRUCTIONS** with your optional surface mount kit.

**Note: Run electric wire under the surface mount mirror side, down to the bottom to your electrical connection.**

6. When cleaning your new Afina cabinet, we recommend a mild cleanser, applied first to a rag or paper towel. Do not spray directly on to the mirror or frame.  
We are confident your **AFINA** cabinet will reflect the quality and prestige you wish to convey in your home or business environment.

[www.afinacorporation.com](http://www.afinacorporation.com)

**ELECTRICAL INSTRUCTIONS ON BACK PAGE→**

# Illume Electrical Connection

The LED Driver inside the enclosed Illume mirror has already converted the electric to 110 volts. You can connect the 24" lead coming out of the center of the back of the mirror directly to your electrical connection box. The lead contains 3 wires:

-Green = GROUND wire..... connect to ground wire in your box, or to the box as a ground.

-White = NEUTRAL wire..... connect to the White neutral wire in your box.

-Black = HOT wire..... connect to the Black hot wire in your box.

The Illume wires get connected to your 110 Volt electric box that you should have placed in the wall, behind where your Illume Mirror will be mounted. It doesn't have to be exactly in the center as the lead wire gives you flexibility in the placement. However we suggest you place it somewhere towards the center.

When you hard wire your new Illume mirror you may connect it to your wall switch and/ or use an "LED" Dimmer Switch.