



- For protection in shipping, the GLASS SHELVES for your cabinet have been tucked under the top or bottom of the cabinet body. They are clearly identified by a label marked "GLASS SHELVES". Please look carefully and remove before installation.
- SHELF PINS are inside the cabinet in an envelope marked "SHELF PINS". Remove before installation of cabinet.
- It is important to make sure the cabinet body is level and plumb upon installation. Use a leveling instrument to insure accuracy, or the door may not close and/or secure itself properly.
- You can hang your new cabinet hinge left or hinge right just by turning the cabinet over.
- When RECESSING the cabinet, use the two pre-drilled holes (top and bottom) on each side of the cabinet interior. Screws are not supplied - as we do not know the type of material you are going into (i.e., wood studs or metal studs). Make sure the cabinet is level and plumb before securing into framing studs.
- When SURFACE MOUNTING [with Optional SM Kit]
[Click Here to See separate SURFACE MOUNTING INSTRUCTIONS.](#)
- When cleaning your new AFINA bath cabinet, we recommend a mild cleanser, applied first to a rag or paper towel. Do not spray cleaner directly onto the mirror or frame.